

SCANNED, #




Figure 1




Figure 2 A

275

ENTER

USER DEFINES A SET OF GLOBAL RESOURCES FOR A  
FIRST DESIGN PROJECT, E.G., USING THE GLOBAL  
PARAMETER WINDOW

277

USER SAVES THE SET OF GLOBAL PARAMETERS AS A  
DEFAULT SETTING, E.G., USING A FILENAME OR OTHER  
DESCRIPTIVE LABEL

279

USER STARTS OR OPENS A SECOND PROJECT

281

USER CAN RECALL THE PREVIOUSLY SAVED SET OF  
GLOBAL PARAMETERS AND APPLY THEM TO THE  
SECOND DESIGN PROJECT WITHOUT NEEDING TO  
DEFINE THEM AGAIN FOR THE SECOND PROJECT

283

RETURN

FIG. 2B

5505 5505 5505 5505 5505

No. 5505  
Engineer's Computation Pad



Global Resources	
CPU_CLOCK	24-MHz
32K_SELECT	INTERNAL
PLL_MODE	DISABLE
:	:

Annotations around the table:

- Callout 310 points to the top-left corner of the table.
- Callout 330 points to the left edge of the table.
- Callout 340 points to the right edge of the table.
- Callout 300 points to the top-right corner of the table.
- Callout 320 points to the bottom-left and bottom-right corners of the table.

Figure 3

No. 5505  
Engineer's Computation Pad




Figure 4





Figure 5

## newproject - PSoC Designer - [Device Editor]



## newproject - PSoC Designer - [Device Editor]




Fig.

10  
11




Figure 1

208240 " Taxicabs

No 5505  
AUM Engineers Computation Pad




Figure 2A

DESIGN DATA CENTER




FIG. 2B

Global Resources

The diagram shows a table titled "Global Resources" with four rows. The first row contains the header "CPU\_CLOCK" and "24-MHz". The second row contains "32K\_SELECT" and "INTERNAL". The third row contains "PLL\_MODE" and "DISABLE". The fourth row contains two ellipsis symbols ("..."). To the left of the table, there is a vertical line with a label "No. 5505 Engineer's Computation Pad" and a small logo. Above the table, there are several annotations: "310" with an arrow pointing to the top-left corner of the first row; "320" with arrows pointing to the top-right corner of the first row and the bottom-right corner of the table; "330" with an arrow pointing to the left edge of the first row; "340" with an arrow pointing to the right edge of the table; and "300" with an arrow pointing to the top edge of the table.

Global Resources	
CPU_CLOCK	24-MHz
32K_SELECT	INTERNAL
PLL_MODE	DISABLE
...	...

Figure 3

2023-10-12 15:00:00

No SSOs  
Engineer's Computation Pad





Figure 4

2020-07-09 15:26:00






Fig. 6.




Fig.